

Resetting the SMC for Laptop Batteries Not Charging

To reset the SMC with non-removal batteries:

- Shut down the computer.
- Plug in the MagSafe or USB-C power adapter to a power source and to your computer.
- On the built-in keyboard, press the (left side only) Shift-Control-Option keys and the power button at the same time.
- Release all the keys and the power button at the same time.
- Press the power button to turn on the computer.

On MagSafe power adapters, the LED might change states or temporarily turn off when you reset the SMC.

To reset the SMC with removable batteries:

- Shut down the computer.
- Disconnect the MagSafe power adapter from the computer if it's connected.
- Remove the battery.
- Press and hold the power button for five seconds.
- Release the power button.
- Reconnect the battery and MagSafe power adapter.
- Press the power button to turn on the computer.